




NESTiG

The Rook Toy Chest




Please read all instructions before assembly
and use of product!


Lisez toutes les instructions avant
d'assembler et d'utiliser le produit!





⚠ WARNING:
 TO AVOID INJURY: Only use under the direct supervision of an adult. The maximum weight for this product is 45.0 lbs (20kgs).


Product Parts Detail





A x16

 8x30


B x4

 1/4x50

C x6

 7x50

D x8

 4.0x45


E x8


F x8


G x1


Assembly Instructions

01




A x16




E x8



02




Be sure the dowels on pieces 2 and 3 all face the same direction



F x8




03





B x4




C x6




G x1




04



05



06





nestig.com



Nestig, Inc.

hello@nestig.com

PO Box 1106, New York, NY 10023